



Standard installation for air pre-heating in winter and air pre-cooling in summer with an brine-to-air heat exchanger. Summer cooling requires a 100%-bypass option in the ventilation system behind.

netec

Installation scheme Brine-to-air-heat exchanger

Netec Energietechnik, Woldemarstr. 37, D-32756 Detmold
Tel. 0049 - (0)5231- 390 748 info@sole-ewt.de www.sole-ewt.de